


Installation Instruction



(E) Warnings:

1. Input voltage and input power are indicated in the luminaries label
2. Don't replace any accessories when the luminaire is at work.
3. This luminaire is suitable for indoor use only.
4. The luminaires are only to be installed outside arm reach.
5. Max. weight and max. input current are not more than the rated parameters of track used.
6. Under no circumstances, can the luminaire be covered with heat insulation gasket or similar materials.
7. The light source contained in this luminaire shall only be replaced by the manufacturer or local distributor or a similar qualified person in order to avoid hazards.
8. To avoid potential lamp failure, the luminaire should be switched off at least once a week.



Pendant & Surface mounted version		Wall Light (single head)		
	STEP 1 take out the connector by anticlockwise direction 	STEP 1 take out by anticlockwise direction 	STEP 2 main power supply 	
	STEP 2 	STEP 3 secured the bracket on the wall 	STEP 4 groove & tab 	STEP 4 twist lock by clockwise direction
	STEP 3 1. main power supply groove & tab 	STEP 3 1. main power supply groove & tab 2. twist lock in clockwise direction 	Wall Light (double head)	
Track Light		STEP 1 take out 2 heads by anticlockwise direction 		
STEP 2 OFF 3 phase 		STEP 2 main power supply 		
STEP 3 ON CLICK! 		STEP 3 secured the bracket on the wall 		
STEP 4 OK! 		STEP 4 groove & tab twist lock by clockwise direction 		
Surface mounted light				
STEP 1 		STEP 2 main power supply 		
STEP 3 		STEP 3 		