

## Installation Instruction

INPUT: 220–240V, 50/60Hz

ATTENTION: YOU HAVE TO CUT OFF THE POWER BEFORE INSTALLING THE LAMP

