

INSTALLATION INSTRUCTION

Important Information

- Product must be installed in accordance with the current regulations and electrical codes in the country of installation and all wiring must be done by a qualified electrician.
- These products are designed for connection to a 100-305VAC 50/60Hz supply.
- Any broken or damaged parts should be replaced as soon as possible.
- We will not accept responsibility for any claims arising from a poor installation

Important User Safety Advice

- Make sure to observe and follow all necessary health and safety precautions when installing.
- Always disconnect power before installation or servicing

Kit Contents

(1) Luminaire, (1) LED Driver

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE


Luminaire Assembly

1. Check you have all the tools and accessories required to complete the installation correctly.
2. Fix luminaire to the mounting plate
3. The power supply is installed in the pole, and the side with the thermal pad should be installed on the mounting surface in the pole, which is help to heat dissipation.
4. Connect the driver output lead to the luminaire plug as indicated in below diagram using the connector provided
5. Turn on power supply and test for correct operation.

Electrical Connections

200-240VAC 50/60Hz / Class I

Note: Class I products must always be Earthed/Grounded



Dimming

If you wish to dim this fitting, please ensure that you have purchased the dimmable model. Connect the supply dimming positive wire to the positive (+) terminal, connect the supply dimming negative wire to the negative (-) terminal. If dimming is not required, ensure to isolate the supply dimming cables.